





# Fiche technique UT-2000HD/ Technical sheet UT-2000HD


<b>Application</b>	Commerciale, Institutionnelle Commercial , Institutionnal
<b>Usage</b>	Moyen/Robuste —Medium/Heavy duty
<b>Norme / Standard</b>	Conforme—Complies with ANSI/BHMA A156.14 Grade 1



**HAUTEUR DE L'OUVERTURE:**  
ROUGH OPENING HEIGHT:  
HAUTEUR DE PORTE/DOOR HEIGHT  
+3 7/8" [+98mm] MIN.  
+4 3/4" [+120mm] MAX.



UT-2000HD



Pour porte/For door 1 3/8" à 1 3/4"  
de/of 250 Livres/Pounds (110Kg) Max.

Architectural  
**UNIQUE**

Votre satisfaction, notre fierté!













Tél.: 514 351-5454 / Fax: 514 351-5554  
uniqueproduitarchitectural.com


Systemes  
**UNITRACK**  
Systems

**UT-2000HD**

Dessin de référence drawing

DESSIN / DRAWING No: REF-UT2000HD DATE: 16/05/2014 PAGE: 1/1


Liste des pièces ensemble UT-2000HD / Parts list UT-2000HD series		
Nom / Name	Image / Picture	Qté / Qty
Rail UT-2000HD track		1
Chariot / Hanger UT-2010		2
Palque de fixation / Fixing plate		2
Boulon en T / T-bolt		2
Roue pivotante / spinwheel UT-2040		2
Guide décentré UT-1050 Offset guide UT-1050		2
Rondelle de blocage dentée Tooth washer		4
Écrou hexagonal 5/16" HEX nut		4
Butoir / Stop UT-DS200		2
Vis auto-perçante / Self-drilling screw #10x2"		4
Vis / Screw #10x1-3/4"		8
Vis / Screw #8x3/4"		16



1-Cut rail 1/8" LESS than the TOTAL opening width.



2-Slide hangers UT-2010 into rail, making sure sleeve openings are all on the front side and screw the rail into the opening's header.



3a: Drill a 3/8" diameter hole at least 2" deep, at 3-1/2" from each end of the door.

3b: Drill 1/8" diameter holes 1-1/2" deep for the fixing plate screws.




4-Proceed with the assembly of the fixing plates as follows:

A: Take a T-bolt, insert a toothed washer, two hex nuts, and then another toothed washer.




B: Insert the fixing plate UT-2020.



C: Insert the spinwheel UT-2040.




5-Align the fixing plate with holes drilled in step 3B. Screw on the fixing plates using #10 x 1-3/4" screws.



6-Position the door under the hangers and insert the T-bolts into the sleeve openings.



7-Place the guides UT-1050 on the floor, on both sides of the door and screw into place using #8 x 3/4" screws.



8-Set the door level and adjust its height by screwing or unscrewing the spinwheel UT-2040.













9-Once adjustment is made, lock the bolt by tightening the 5/16" hex nut.

10-To avoid accidental door detachment, tighten the other 5/16" hex nut against the hanger.

Note: If installing a fascia, it is important to leave a 1/2" space between the door and the fascia to allow removal and replacement of the door.

11-Slide the stopper UT-DS200 into the rail at the desired stop point and attach to rail using #10 x 2" screws.

<p>HAUTEUR DE L'OUVERTURE: ROUGH OPENING HEIGHT:</p>
<p>HAUTEUR DE PORTE/DOOR HEIGHT +3 7/8" [+98mm] MIN. +4 3/4" [+120mm] MAX.</p>

Parts list UT-2000HD/UT-2000SHD series		
Name	Picture	Quantity
UT-2000 /UT-2000S track		1
Hanger UT-2010		2
Fixing plate UT-2020		2
T-bolt		2
Spinwheel UT-2040		2
UT-1050 offset guide		2
Tooth washer		4
5/16" HEX nut		4
Stop UT-DS200		2
Self-drilling screw #10x2"		4
Screw #10x1-3/4"		8
Screw #8x3/4"		16