




Fiche technique UT-2000S/ Technical sheet UT-2000S

Application	Commerciale, Institutionnelle Commercial, Institutionnal
Usage	Moyen/Robuste — Medium/Heavy duty
Norme / Standard	Conforme—Complies with ANSI/BHMA A156.14 Grade 1



Butoir/Doorstop
(UT-DS200)



Pour porte/For door 1 3/8" à/to 1 3/4"
de/of 150 Livres/Pounds (65Kg) Max.

Architectural
UNIQUE













Votre satisfaction, notre fierté!


Systèmes
UNITRACK
Systems
UT-2000S

Dessin de référence drawing

Tél.: 514 351-5454 / Fax : 514 351-5554
uniqueproduitarchitectural.com

DESSIN / DRAWING No: REF-UT2000S
DATE: 16/05/2014
PAGE: 1/1


Liste des pièces ensemble UT-2000S / Parts list UT-2000S series		
Nom / Name	Image / Picture	Qté / Qty
Rail UT-2000S track		1
Chariot / Hanger UT-2010		2
Palque de fixation / Fixing plate		2
Boulon en T / T-bolt		2
Roue tournante / spinwheel		2
Guide décentré UT-1050 Offset guide UT-1050		2
Rondelle de blocage dentée Tooth washer		4
Écrou hexagonal 5/16" HEX nut		4
Butoir / Stop UT-DS200		2
Vis auto-perçante / Self-drilling screw #10x2"		4
Vis / Screw #10x1-3/4"		8
Vis / Screw #8x3/4"		10



1-Cut rail 1/8" LESS than the TOTAL opening width.



2-Slide hangers UT-2010 into rail, making sure sleeve openings are all on the front side and screw the rail into the opening's header.



3a: Drill a 3/8" diameter hole at least 2" deep, at 3-1/2" from each end of the door.

3b: Drill 1/8" diameter holes 1-1/2" deep for the fixing plate screws.




4-Proceed with the assembly of the fixing plates as follows:

A: Take a T-bolt, insert a toothed washer, two hex nuts, and then another toothed washer.




B: Insert the fixing plate UT-2020.



C: Insert the spinwheel UT-2040.




5-Align the fixing plate with holes drilled in step 3B. Screw on the fixing plates using #10 x 1-3/4" screws.



6-Position the door under the hangers and insert the T-bolts into the sleeve openings.



7-Place the guides UT-1050 on the floor, on both sides of the door and screw into place using #8 x 3/4" screws.



8-Set the door level and adjust its height by screwing or unscrewing the spinwheel UT-2040.













9-Once adjustment is made, lock the bolt by tightening the 5/16" hex nut.

10-To avoid accidental door detachment, tighten the other 5/16" hex nut against the hanger.

Note: If installing a fascia, it is important to leave a 1/2" space between the door and the fascia to allow removal and replacement of the door.

11-Slide the stopper UT-DS200 into the rail at the desired stop point and attach to rail using #10 x 2" screws.

**HAUTEUR DE L'OUVERTURE:
ROUGH OPENING HEIGHT:**
HAUTEUR DE PORTE/DOOR HEIGHT
+3 7/8" [+98mm] MIN.
+4 3/4" [+120mm] MAX.

Parts list UT-2000 series		
Name	Picture	Quantity
UT-2000 track		1
Hanger UT-2010		2
Fixing plate		2
T-bolt		2
spinwheel		2
UT-1050 offset guide		2
Tooth washer		4
5/16" HEX nut		4
Stop UT-DS200		2
Self-drilling screw #10x2"		4
Screw #10x1-3/4"		8
Screw #8x3/4"		10